



UPC-MARATHON

FLO-TRONIC PLUS™

User Manual



CONNECT WITH US



MASTERING
STRENGTH.
WORLDWIDE.



MANUAL#: 403

Revision	Date	Technician	Revision Description
R6	4/9/2020	JG	Updated to represent Rev.3 FTP box
R5	3/11/2020	DW	Added Flow Alarm Setup section
R4	8/12/2016		
R3	4/15/2013		
R2			
R1			
R0	12/21/2010		

THIS MANUAL IS SUPPLIED ELECTRONICALLY.

COPYRIGHT^(C)

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual, or otherwise, without prior written permission of United Process Controls Inc. (UPC-MARATHON).

The information contained in this document is STRICTLY CONFIDENTIAL and PROPRIETARY to UPC-Marathon and shall not be: i) reproduced or disclosed in part or in whole, ii) used for any design or manufacturing of heat treating and/or control equipment, or any other purpose except for that which it is supplied under the terms of the Contract, unless the express written authorization is obtained from UPC-Marathon.

Drawings and photographs included in the documentation are the property of UPC-Marathon, and it is strictly forbidden to reproduce them, transmit them to a third party, or use them for manufacturing and/or design of equipment. Sub-licensing of any technical information contained in this Documentation is strictly forbidden under the terms of the Contract.

UPC-Marathon reserves the right to modify this document without prior notice.

DISCLAIMER:

The **FLO-TRONIC PLUS™** is to be used by the industrial operator under his/her direction. UPC-Marathon is not responsible or liable for any product, process, damage or injury incurred while using the **FLO-TRONIC PLUS™**. UPC-Marathon makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties or merchantability or fitness for any purpose.

WARRANTY:



UPC-Marathon warrants its goods as being free of defective materials and faulty workmanship. Contact your local sales office for warranty information. If warranted goods are returned to UPC-Marathon during the period of coverage, UPC-Marathon will repair or replace without charge those items it finds defective. The foregoing is Buyer's sole remedy and is in lieu of all other warranties, expressed or implied, including those of merchantability and fitness for a particular purpose. Specifications may change without notice. The information we supply is believed to be accurate and reliable as of this printing. However, we assume no responsibility for its use.

TECHNICAL ASSISTANCE

For all questions or concerns regarding the operation of the **FLO-TRONIC PLUS™**, please consult the last page of this manual for contact information.



Table of Contents

1	WARNING	5
2	MANUAL OVERVIEW	5
3	FLOW SENSOR INTRODUCTION	6
3.1	How it works.....	6
4	SPECIFICATIONS.....	7
5	INSTALLATION AND WIRING	8
5.1	Flo-Meter Installation	8
5.2	Wiring Guidelines	8
5.3	Wiring Connections	9
5.4	Circuit Protection	9
5.5	Wiring Terminal	10
5.6	Basic Wiring Diagram.....	11
5.7	Alarm Relay Wiring	11
6	CALIBRATION AND FIELD SERVICE	11
6.1	Measurement of Output Signal	12
6.2	Adjustment of Output Signal	12
7	MAINTENANCE	13
8	CALCULATIONS	13
9	TROUBLESHOOTING	14
10	FLOW ALARM SETUP	15
11	APPENDIX “A” - DRAWINGS	18
12	CUSTOMER SUPPORT	19



1 WARNING

Thank you for purchasing control equipment from UPC-Marathon. We want your new control equipment to operate safely. Anyone who uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest version of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please consult the last page of this manual for contact information.



WARNING: Read this manual thoroughly before using Flo-Tronic.



WARNING: This unit contains ESD (Electrostatic Discharge) sensitive parts and assemblies. Static control precautions are required when installing, testing, servicing or repairing this assembly. Component damage may result if ESD control procedures are not followed. If you are not familiar with static control procedures refer to an applicable ESD protection handbook.



WARNING: Flo-Meter must be earth grounded. Ungrounded Flo-Meters may become a source of Ignition.

2 MANUAL OVERVIEW

The Purpose of this Manual



Thank you for purchasing a Flo-Tronic Plus™ Flow Sensor. This manual shows you how to install, wire and maintain UPC-Marathon's Flo-Tronic Plus. It also helps you understand how to interface it to other devices in a control system. This manual contains important information and should be read and understood by all individuals who install, use or service this equipment.

Supplemental Manuals

The Installation and Operation of UPC-Marathon Flo-Meters manual contain technical information as well as precautions about UPC-Marathon Flo-Meters.

Conventions Used



When you see the exclamation point icon in the left-hand margin, the paragraph to its immediate right will be a warning. This information could prevent injury, loss of property, or even death in extreme cases. Any warning in this manual should be regarded as critical information that should be read in its entirety. The word **WARNING** or **CAUTION** in boldface will mark the beginning of the text.



When you see the “notepad” icon in the left-hand margin, the paragraph to its immediate right will be a special note.

3 FLOW SENSOR INTRODUCTION

The UPC-Marathon Flo-Tronic Plus™ utilizes a sensor to read the position of the float rod indicator on a UPC-Marathon Flo-Meter™. The unit provides both electrical and mechanical indication of flow. The unit is factory calibrated to provide linear and accurate flow measurement. If necessary, the Flo-Tronic may be “field calibrated”.

3.1 How it works

Magnet assembly attached to float rod of the UPC-Marathon Flo-Meter interacts with a magnetostrictive linear position sensor installed in Flo-Meter sensing head. A strain pulse is induced in a specially designed waveguide by the momentary interaction of two magnetic fields. One field comes from a moving magnet, which passes along the outside of the sensing tube, the other field from a current pulse launched along a wire inside the waveguide. The interaction between these two magnetic fields produces a strain pulse which travels at sonic speed along the waveguide, until the pulse is detected at the head of the transducer. The position of the moving magnet is precisely determined by measuring the elapsed time between the launching of the electronic pulse and the arrival of the strain pulse. As a result, accurate non-contact sensing of the Flo-Meter's indicator is achieved. The indicator position is directly related to the Flo-Meter's flow rate and is represented by a proportional analog electrical signal.



4 SPECIFICATIONS

General Specifications		
Operation Specification		
Measurement	Accuracy	$\pm 0.4\% \text{ FS} + 1.6\% \text{ Rd}$
	Repeatability	$< 0.5\% \text{ FS}$
	Turndown Ratio	1:40 (2.5 ... 100%)
Electrical Power	Operating Voltage	24VDC $\pm 10\%$
	Power Consumption	75mA
Analog Output	Ranges Selectable	Current: 4-20mA or 0-20mA Voltage: 0-10VDC or 2-10VDC
	Voltage Output	
	Short Circuit Protection	YES
	Short Circuit Current	0.875mA
	Min Load Impedance	1k Ohm
	Current Output	
	Open Circuit Voltage	24VDC
	Max Load Impedance	500 Ohm
Relay Output	Type	SPST
	Contact Rating	0.5A @ 30VDC
	Alarm Logic	No power or alarm condition de-energize relay
Environment	Operating Temp	0°C to 65°C (32°F to 150°F)
	Humidity	20 to 90% RH (non-condensing)
	Storage Temp	-20°C to 65°C (-4°F to 150°F)
	Enclosure Rating	IP 65
	Installation Location	Keep from corrosive gas and liquid



5 INSTALLATION AND WIRING

5.1 Flo-Meter Installation

The Installation and Operation of UPC-Marathon Flo-Meters manual contains instructions on the proper installation of the Flo-Meter. Read all CAUTIONS and WARNINGS before proceeding.

The Flo-Tronic -Meter is shipped as a complete unit. Before installing the Flo-Meter, carefully remove the Flo-Tronic Sensor, to achieve this lay the unit on its side on a work bench or table. Then hold the Flo-Tronic unit with one hand, while unscrewing the union nut counters clockwise with the other hand to loosen it.



CAUTION: Once the Flo-Tronic is loose from the Flo-Meter make sure to pull the Flo-Tronic from the Flo-Meter straight back off the float rod assembly. Moving the Flo-Tronic to one side or another during removal may result in damage to the float rod assembly.

Remove the Float Rod Assembly and store it in a safe location until Flo-Meter body is installed and mounted. Once the Flo-Meter is installed, remove the red tape from the float rod and insert the float rod assembly into the Flo-Meter body. Fill the sight glass tube with UPC-Marathon Flo-Meter oil so that the level of oil is approximately one (1) inch from the top. Then carefully install the Flo-Tronic on to the Flo-Meter.




Do not put oil in the sight glass tube of meters used for **oxygen** or **methanol** service. Oxygen Flo-Meters should be run dry, or with distilled water. Flo-Meters for Methanol service will automatically fill the sight glass tube with Methanol when in service.



WARNING: Do not fill the sight glass tube with Flo-Meter oil on meters used for oxygen service. Use of oil may cause fire or explosion. Serious personal injury may result from fire or explosion.

5.2 Wiring Guidelines

Your company may have guidelines for wiring installation. If so, you should check those before you begin the installation. Here are some general things to consider:





- Use the shortest wiring route whenever possible.
- Use shielded wiring for all signal wiring and ground the shield at the Field Device end. **DO NOT** ground the shield at both the Flo-Tronic Sensor and Field Device.
- Do not run the signal wiring next to large motors, high current switches, or transformers. This may cause noise problems.
- Route the wiring through an approved cable housing to minimize the risk of accidental damage. Check local and national codes to choose the correct method for your application.
- Be sure to leave enough slack in the cables to allow easy removal of the Flo-Tronic from the Flo-Meter for maintenance. If seal tight or similar conduit is used, be sure to provide an adequate loop of conduit for maintenance access.

5.3 Wiring Connections

All wiring connections are located inside the main box. To access the wiring terminals remove the (4) four screws located on the front of the box and remove the cover.



CAUTION: To reduce the risk of electrical shock and also to prevent damage to the Flo-Tronic and the Field Device. It is advised to turn off the supply power to the Flo-Tronic and Field Device before connecting or disconnecting any wires.



WARNING: Any electrical or mechanical modification to this equipment without prior written consent of United Process Controls will void all warranties, may result in a safety hazard, and may void the CE listing.




Use 18-22AWG shielded cable for the signal wiring. It is recommended to run all signal wires in a separate steel conduit. The shield wire should only be connected at the Field Device end. Do not connect shield wire on both ends.

5.4 Circuit Protection

The Flo-Tronic is equipped with built-in over-voltage and short circuit protection. The unit may require recycling of power to reset once the fault condition is removed.

5.5 Wiring Terminal



Field Wiring Termination Pinouts:

X1 - G-series sensor

1. 24 VDC (+) (red)
2. 24 VDC (-) (black)
3. Shield
4. Signal IN (+) (gray)
5. Signal IN (-) (pink)

X2 - Power Supply Input (min. 1.5A power supply)

1. 24 VDC (+) (red)
2. 24 VDC (-) (black)
3. Ground (green)

X3 - Circuit Signal Output

1. 4-20mA (+) (green)
2. 4-20mA (-) (white)


X4 - Alarm Relay

1. Common (C)
2. Relay (NC)
3. Relay (NO)

X5 – MODBUS Communication Port Requires separately purchased cable

****Note:** During wiring & installation it is recommended that a 5P shielded cable be used to terminate X2 and X3 connections. X4 should use a separate 3P cable.

5.6 Basic Wiring Diagram



5.7 Alarm Relay Wiring

The Flo-Tronic Plus includes an alarm relay, on power up the relay is energized to indicate that the unit has power. The relay will de-energize under the following alarm conditions:

- Loss of Power
- Loss of Sensor Signal
- Over Temperature Condition
- Output Wiring Problem



CAUTION: Relay is for use with 30VDC or less ONLY!!! Use of any other voltage may result in damage to unit and poses a potential fire risk.



WARNING: An external relay must be used if connecting alarm contacts to a load over 0.5 Amps. Use of alarm contact with loads over 0.5 Amps will result in relay failure and poses a potential risk of fire.


6 CALIBRATION AND FIELD SERVICE

The Flo-Tronic Plus output signal is calibrated at the factory and should be received calibrated, but in some cases the unit may require field calibration of the electronics. If you find that the analog output signal is not correct in relation to the indicated flow, you can recalibrate the output by the adjustment of the “Zero” and “Span” potentiometers located inside the sensor box.



CAUTION: Do not turn potentiometers excessively as these adjustments are sensitive.

6.1 Measurement of Output Signal



The best way to measure the output signal is to disconnect the unit from the field device and connect a multi-meter across terminals 1&2 on strip X3. Set the multi-meter to measure the correct signal the unit is setup for.

If you are unsure what the output signal is, refer to “Analog output configuration” located on page 8.

6.2 Adjustment of Output Signal

This procedure requires the ability to move the float rod from 0 “Zero” flow to 100% “Full Scale” flow.

Sensor Zero:

**** Indicator must be at 0% of scale. ****

Press and hold both sensor zero/span buttons for five (5) seconds, until both lights begin to flash. Momentarily release buttons and press and hold the “**Sensor Zero**” button for five (5) seconds until Alarm LED (red) begins to flash, then release. Both LEDs will turn off for a moment and then the green LED will flash & illuminate, indicating the “ZERO” calibration has been accepted.

Sensor Span:

**** Indicator must be at 100% of scale. ****



Immediately move the indicator and hold steadily at 100% of scale. Press and hold the “**Sensor Span**” button for five (5) seconds until the Power LED (green) illuminates, then release. (The green LED will illuminate steadily indicating the “SPAN” value has been accepted.)



CAUTION: Make sure supply fluid to Flo-Meter has been **SHUT-OFF** before removing the Flo-Tronic from the Flo-Meter. Failure to do so may result in accidental death or explosion.

7 MAINTENANCE

The Flo-Tronic is a magnetic based sensor which is unaffected by dirt. The dampening oil can be soiled to the point that it is not possible to visually read the flow on the Flo-Meter and the unit will still accurately determine the position of the float rod assembly.

The Flo-Meter is a mechanical device that requires regular maintenance in order to maintain accuracy. All Flow Meters are susceptible to dirt affecting its accuracy. Although not all manufactures have a means to gauge when the Flo-Meter requires maintenance. UPC-Marathon Flo-Meters on the other hand have a built-in indication when the Flo-Meter requires maintenance, which is the dampening oil. When the oil becomes soiled it is indication maintenance on the Flo-Meter is needed. The frequency of maintenance intervals will vary depending on the cleanliness of the gas being used. To replace the oil will require the removal of the Flo-Tronic; refer to the installation section of this manual for instructions. Also, during these maintenance intervals, it is recommended that all gaskets and o-rings are inspected for signs of wear or damage. Replace worn or damaged seals. Gasket kit sets are available from UPC-Marathon if needed.

8 CALCULATIONS

Determine output for a given flow rate

1. First determine the % of scale represented by:

$$\% \text{ of Scale} = \frac{\text{Actual Flow (cfh)}}{\text{Full Scale Flow (cfh)}}$$

2. Then the Output is calculated by:

$$\text{For 4-20mA } \text{mA} = (\% \text{ of Scale} \times 16) + 4$$

$$\text{For 0-20mA } \text{mA} = \% \text{ of Scale} \times 20$$

$$\text{For 2-10VDC } \text{VDC} = (\% \text{ of Scale} \times 8) + 2$$

$$\text{For 0-10VDC } \text{VDC} = \% \text{ of Scale} \times 10$$

Example 1:

Scale Plate is 750CFH

Indicated Flow is 500CFH

Output range = 4-20mA

$$\frac{500}{750}$$

$$(.6666 \times 16) + 4 = 14.65\text{mA}$$
$$= .6666$$



Determine the flow rate from the output

- First determine % of Full Scale:
$$\text{4-20mA Range} = \frac{\text{mA} - 4}{16}$$
$$\text{0-20mA Range} = \frac{\text{mA}}{20}$$
$$\text{0-10VDC Range} = \frac{\text{VDC}}{10}$$
$$\text{2-10VDC Range} = \frac{\text{VDC} - 2}{8}$$
- Then Actual Flow is calculated by:
Actual Flow = % of Full Scale x Full Scale Flow

Example 2:

Find the flow rate for a 4-20mA signal of 12.00mA and a Flow Meter Scale of 1000CFH

$$\frac{12 - 4}{16} = .5 \text{ or } 50\%$$

$$.5 \times 1000 = 500\text{CFH}$$

9 TROUBLESHOOTING

Diagnostic Lights

The Flo-Tronic has a comprehensive diagnostic system. The diagnostic lights are displayed on the front panel of the unit.

POWER - The Power LED indicates when power is applied.

ALARM – The Alarm LED indicates device error or a probe reading beyond range of flow alarm.

COMMON BLINK SEQUENCES

Alarm LED is ON continuously and Power LED blinks:

- 4 times 0.2sec ON / 0.3sec OFF and 1sec pause – device has encountered some problems with external 24V power supply.
- 2 times 0.2sec ON / 0.3sec OFF and 1sec pause – device has encountered some problems with internal 3.3V power supply.


Power LED is ON continuously and Alarm LED blinks

- 4 times 0.2sec ON / 0.3sec OFF and 1sec pause – device has encountered an error within the Inputs/Outputs. This alarm consists of the following sub errors:
 - Probe reading above/below calibrated range.
 - Probe is not responding.
 - Open-loop circuit detected on an analog output.




10 FLOW ALARM SETUP

1. Connect the FTP MODBUS communications cable from X5 to the desired ethernet port on Windows PC.
2. On the PC go to **START>CONTROL PANEL> NETWORK AND SHARING CENTER> CHANGE ADAPTER SETTINGS** to bring up the connection manager.




3. Double-click the connection the FTP is connected to. This will bring up the network properties for that connection.




4. Double-click on “Internet Protocol Version 4(TCP/IPv4). Under “Use the following IP address” enter the following (for default IP):
IP address: 192.254.0.4
Subnet mask: 255.255.255.0
Default gateway: “Blank”

Select OK to close all windows.

5. Open web browser and type “<http://169.254.0.3/>”
6. Log in to the FTP Interface via the FTP Login Page.
 - a) Log in as “Supervisor” using the password “flow”.



7. Select the configuration tab.





8. If the Flow Alarm feature is active (set in factory), it will show on the Flow Signal Configuration page.
9. Type in your set point (in percent of scale).
 - a) Select “below setpoint” or “above setpoint” from the dropdown menu.
 - b) Click on “Apply”.

10. If your settings saved correctly, the bottom ribbon on the interface screen will turn green and read “Operation executed successfully”.



11 APPENDIX “A” - DRAWINGS

Available on demand.



12 CUSTOMER SUPPORT

Americas	Asia	Europe
<u>support.na@group-upc.com</u> USA: +1 414 462 8200 Canada: +1 514 335-7191	<u>service@mmichina.cn</u> Shanghai: +86 21 3463 0376 Beijing: +86 10 8217 6427	<u>support.eu@group-upc.com</u> France: +33 3 81 48 37 37 Germany: +49 7161 94888-0 Poland: +48 32 296 66 00

Reach us at www.upc-marathon.com

UPC-Marathon brings together leading brands to the heat-treating industry including Atmosphere Engineering, Furnace Control, Marathon Monitors and Process-Electronic, and Waukee Engineering. We provide prime control solutions through our worldwide sales and services network with easy-to-access local support.

